

TOUR

CHANNEL	VALUE	FUNCTION
1	0 ↔ 255	MASTER DIMMER
2	0 ↔ 255	RED (or STEP TIME when CUS.01-CUS.10 in CH8 is activated)
3	0 ↔ 255	GREEN (or FADE TIME when CUS.01-CUS.10 in CH8 is activated)
4	0 ↔ 255	BLUE
5	0 ↔ 255	WHITE
6		COLOR MACRO & WHITE
	0 ↔ 10	NO FUNCTION
	11 ↔ 30	RED 100% / GREEN UP / BLUE 0%
	31 ↔ 50	RED DOWN / GREEN 100% / BLUE 0%
	51 ↔ 70	RED 0% / GREEN 100% / BLUE UP
	71 ↔ 90	RED 0% / GREEN DOWN / BLUE 100%
	91 ↔ 110	RED UP / GREEN 0% / BLUE 100%
	111 ↔ 130	RED 100% / GREEN 0% / BLUE DOWN
	131 ↔ 150	RED 100% / GREEN UP / BLUE UP
	151 ↔ 170	RED DOWN / GREEN DOWN / BLUE 100%
	171 ↔ 200	ALL LED AT FULL OUTPUT
	201 ↔ 205	WHITE1 & 3200K
	206 ↔ 210	WHITE2 & 3400K
	211 ↔ 215	WHITE3 & 4200K
	216 ↔ 220	WHITE4 & 4900K
	221 ↔ 225	WHITE5 & 5600K
	226 ↔ 230	WHITE6 & 5900K
	231 ↔ 235	WHITE7 & 6500K
	236 ↔ 240	WHITE8 & 7200K
	241 ↔ 245	WHITE9 & 8000K
246 ↔ 250	WHITE10 & 8500K	
251 ↔ 255	WHITE11 & 10000K	

CHANNEL	VALUE	FUNCTION
7		SPECIAL STROBE
	0 ↔ 9	No strobe
	10 ↔ 99	Strobe (slow to fast)
	100 ↔ 109	No strobe
	110 ↔ 179	Lightning strobe (slow to fast)
	180 ↔ 189	No strobe
	190 ↔ 255	Random strobe (slow to fast)
		STROBE 2
	0 ↔ 9	NO FUNCTION
	10 ↔ 255	1-Hz
8		AUTO
	0 ↔ 40	NO FUNCTION
	41 ↔ 50	AUTO01
	51 ↔ 60	AUTO02
	61 ↔ 70	AUTO03
	71 ↔ 80	AUTO04
	81 ↔ 90	AUTO05
	91 ↔ 100	AUTO06
	101 ↔ 110	AUTO07
	111 ↔ 120	AUTO08
	121 ↔ 130	AUTO09
	131 ↔ 140	AUTO10
	141 ↔ 150	CUSTOM01
	151 ↔ 160	CUSTOM02
	161 ↔ 170	CUSTOM03
	171 ↔ 180	CUSTOM04
	181 ↔ 190	CUSTOM05
	191 ↔ 200	CUSTOM06
	201 ↔ 210	CUSTOM07
	211 ↔ 220	CUSTOM08
221 ↔ 230	CUSTOM09	
231 ↔ 255	CUSTOM10	
9		AUTO SPEED
	0 ↔ 255	Since the walking speed (slow to fast)
10		DIMMER SPEED
	0 ↔ 9	RETURN SETTINGS
	10 ↔ 29	NORMAL
	30 ↔ 69	DIM 1
	70 ↔ 129	DIM 2
	130 ↔ 189	DIM 3
	190 ↔ 255	DIM 4

CHANNEL	VALUE	FUNCTION
11		PIXEL SELECTION
	0 ↔ 9	PIX 1,2,3 (STATIC)
	10 ↔ 19	PIX 1 (STATIC)
	20 ↔ 29	PIX 2 (STATIC)
	30 ↔ 39	PIX 3 (STATIC)
	40 ↔ 49	PIX 1,2 (STATIC)
	50 ↔ 59	PIX 1,3 (STATIC)
	60 ↔ 69	PIX 2,3 (STATIC)
	70 ↔ 79	PIX 1,2,3 (STATIC)
	80 ↔ 159	PIX 1,2,3 (STATIC)
	160 ↔ 179	CHASE LEFT-TO-RIGHT)SLOW TO FAST(
	180 ↔ 199	CHASE RIGHT-TO-LEFT)SLOW TO FAST(
	200 ↔ 219	CHASE LEFT-RIGHT-LEFT)SLOW TO FAST(
	220 ↔ 239	RANDON)SLOW TO FAST(
240 ↔ 255	PIX 1,2,3 (STATIC)	
12	0 ↔ 255	ZOOM
13	000 ↔ 200	NO FUNCTION
	201 ↔ 220	ZOOM RESET
	221 ↔ 255	NO FUNCTION